

QTY QTY QTY -041 -043 -045		P/N	DESCRIPTION		
X			D5880-041	STEP ASSEMBLY	
	X D58		D5880-043	STEP ASSEMBLY	
		Х	D5880-045	STEP ASSEMBLY	
1	1	1	D5880-051	STEP TUBE WELDMENT	
1			D5880-1	SOCKET CLAMP	
	1		D5880-3	SOCKET CLAMP	
		1	D5880-5	SOCKET CLAMP	
1	1	1	MS16562-240	SPRING PIN, SLOTTED	


TABLE 1					
P/N "X"	D5880-Y				
D5880-041	D5880-1				
D5880-043	D5880-3				
D5880-045	D5880-5				

С




SECTION A-A SCALE 2X





D5880-04X STEP ASSEMBLY
(DERIVED FROM AERO DESIGN P/N 62340-01)
(SPRING PIN HIDDEN FOR CLARITY)



2

В

NOTES: 1) MATERIAL: N/A

2) FINISH: WHITE GLOSS POWDER COAT PER DART QSI 005 SECTION 4.3

APPLY BLACK ANTI-SKID PAINT (WING WALK) ALONG THE STEP TUBE WELDMENT AS SHOWN
PER DART QSI 005 SECTION 4.4

3) TOLERANCES: PER DART QSI 018 UNLESS OTHERWISE NOTED

- 3) TOLERANCES: PER DART QSI 018 UNLESS OTHERWISE NOTED
 4) UNITS: INCHES UNLESS OTHERWISE NOTED
 5) BREAK SHARP EDGES: 0.005 TO 0.010 MAX
 6) IDENTIFICATION: PER DART QSI 044
 7) WEIGHT: 0.92 lbs
 8) APPLY A THIN FILM OF 3M DP460 SCOTCH-WELD EPOXY ADHESIVE TO SOCKET AND PRESS STEP TUBE
 WELDMENT INTO SOCKET CLAMP. ENSURE STEP TUBE IS FULLY INSERTED BY CHECKING REFERENCED DIMENSION
 9) TRANSFER DRILL HOLE THEN INSTALL SPRING PIN AS SHOWN, AFTER PRESSING STEP TUBE INTO SOCKET CLAMP

RELEASED

2021 MAY 07 P

PPROVED	Α	NEW IS	SSUE JC			20.02.13
	REV.			DESCRIPTION	BY	DATE
	DESIGN		KPT	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA		
	DRAWN		JC			
	CHECKED		SAD	DRAWING NO. D5880 SHE	REV. A	
	MFG. APPR.		FK		SHEET 1 OF 7	
	APPROVED		СР	TITLE		SCALE
	DE APPR.		CP///	STEP ASSEMBLY		NTS
A	DATE 20.02.13			COPYRIGHT © 2020 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT		

